

	ICON Link	Commander VP	Field Commander	Field Commander View
Vezérlés funkciók	Pro licenc	Pro licenc	Pro licenc	Monitor licenc
Auto Restart	✓	✓	✓ ₂	
Auxiliary 1 ON/OFF- Auxiliary 1 Tables	✓	✓	✓	
Auxiliary 2 ON/OFF- Auxiliary 2 Tables	✓	✓		
Auxiliary Relay	✓	✓	✓	
Change Application Depth	✓	✓	✓	
Direction	✓	✓	✓ ₂	
Direction Table	✓	✓	✓ ₂	
DualStop @ Angle	✓		✓	
End Gun Tables	✓	✓ ₁	✓	
Injection (ON/OFF)	✓	✓	✓ ₂	
Multiple Timed Commands	✓	✓	✓	
Pump Command Compatible	✓ ₂	✓ ₂	✓ ₂	
Pump ON/OFF	✓	✓	✓	
Request Reading	✓	✓	✓	
Speed, Speed by Direction	✓	✓	✓	
Start, Start @ Time	✓	✓	✓	
Stop, Stop @ Time, Stop @ Angle	✓	✓	✓	
VRI by Direction	✓	✓	✓	
VRI Injection Compatible	✓	✓	✓	
VRI-iS Full Grid RX	✓			
VRI-iS Legacy RX	✓	✓		
VRI Tables	✓	✓	✓	
VRI Zone RX	✓	✓		
Remote Monitor Features				
Be-/Kikapcsolás	✓	✓	✓	✓
Segédrelé állapot	✓	✓	✓	
Akkumulátor és cella jel erősség	✓	✓	✓	✓
Kábellopás felügyelet	✓	✓ ₂	✓	
Ütközés / Átfedés zóna	✓	✓	✓	✓
Aktuális ciklusidő	✓	✓	✓	✓
Irányítás	✓	✓	✓	✓
Tábla irányítás	✓	✓	✓	
Dual Stop @ Angle	✓	✓	✓	
Végkonzol	✓	✓	✓	
Végkonzol 2	✓	✓	✓	
Végkonzol nyomás	✓ ₁		✓	✓
Áramlási sebesség	✓	✓		
GPS pozíció	✓ ₁	✓ ₁	✓	✓
Jelentések	✓	✓	✓	✓
Időzített parancsok	✓	✓	✓	
Pivot be/Ki	✓	✓	✓	✓ ₁
Pivot nyomás	✓	✓		
Szivattyú Be/Ki	✓	✓	✓	✓
Esőztetés	✓	✓	✓	✓
Fordulatszám	✓	✓	✓	✓
Sebesség	✓	✓	✓	✓
Állapot/Elakadás riasztás	✓	✓	✓	✓
Rendszerhibák	✓	✓		
Hőmérséklet	✓ ₁	✓ ₁	✓ ₁	
Guminyomás ellenőrzés	✓ ₁	✓ ₁		

1 Opcionális
2 Pivot függő